

---

Meridian 1

# Meridian Companion

## Installation and Maintenance Guide

---

553-3601-200

Issue 06

July 1997

---

© 1997 Northern Telecom

All rights reserved

Information is subject to change without notice. Northern Telecom reserves the right to make changes in design or components as progress in engineering and manufacturing may warrant. This equipment has been tested and found to comply with the limits for a Class A digital device pursuant to Part 15 of the FCC rules.

Meridian and Companion are trademarks of Northern Telecom.  
Windows 95 and Windows 3.1 are registered trademarks of Microsoft  
Printed in the United States of America

---

# Contents

---

|                                                                     |           |
|---------------------------------------------------------------------|-----------|
| <b>Contents .....</b>                                               | <b>i</b>  |
| <b>Introduction to Meridian Companion .....</b>                     | <b>1</b>  |
| Preparing to install a Meridian Companion system .....              | 1         |
| Installing a Meridian Companion system .....                        | 2         |
| Installation warnings .....                                         | 4         |
| Safety precautions .....                                            | 6         |
| System overview .....                                               | 10        |
| <b>Installing the hardware .....</b>                                | <b>11</b> |
| Installing Base Stations and Base Station plug-top power supplies . | 12        |
| Installation guidelines .....                                       | 12        |
| Powering a Base Station.....                                        | 14        |
| Mounting a Base Station.....                                        | 14        |
| Installing remote power interconnect units.....                     | 17        |
| Mounting the remote power interconnect unit.....                    | 23        |
| Wiring the RPI unit.....                                            | 25        |
| Upgrading an RPI-8 to an RPI-16.....                                | 29        |
| Mounting a Base Station plug-top power supply.....                  | 30        |
| Installing external antennas and lightning surge arrestors.....     | 33        |
| Planning for an outdoor external antenna.....                       | 35        |
| Installing an outdoor external antenna.....                         | 35        |
| Installing a lightning surge arrestor.....                          | 37        |

|                                                                    |           |
|--------------------------------------------------------------------|-----------|
| Installing a Companion Administration Terminal.....                | 38        |
| Installing the Administration Terminal .....                       | 38        |
| Mounting an Administration Terminal on the wall .....              | 39        |
| Installing Companion Manager.....                                  | 39        |
| Installing the PC Interface Card .....                             | 39        |
| Setting the base address dip switches .....                        | 40        |
| Installing the PCI card .....                                      | 42        |
| Setting the hardware interrupt.....                                | 42        |
| Installing a Remote Access Device .....                            | 43        |
| RAD configuration options.....                                     | 44        |
| Wiring the Time Compression Multiplexing lines.....                | 47        |
| Planning the IPE and CE/PE Module wiring.....                      | 47        |
| Installing Meridian Companion cards .....                          | 55        |
| Normal LED behavior upon installation .....                        | 56        |
| Placing the cards.....                                             | 58        |
| Installing the cards .....                                         | 62        |
| <b>System initialization.....</b>                                  | <b>65</b> |
| Verifying initialization .....                                     | 65        |
| Are arrow indicators flashing? .....                               | 65        |
| Do you see System coldstart ?.....                                 | 65        |
| Did you install more Base Stations?.....                           | 65        |
| Does the display show any of these messages?.....                  | 66        |
| Memory Reset.....                                                  | 66        |
| <b>Programming the Meridian Companion system.....</b>              | <b>69</b> |
| The Meridian Companion Programming and Provisioning<br>Record..... | 70        |
| The Administration Terminal .....                                  | 70        |
| Buttons .....                                                      | 70        |
| Operating the Administration Terminal .....                        | 72        |
| Adjusting the contrast.....                                        | 72        |
| Entering a Configuration programming session .....                 | 72        |

---

|                                                          |           |
|----------------------------------------------------------|-----------|
| Entering an Administration session .....                 | 72        |
| Ending a programming session .....                       | 73        |
| Recording and reporting alarm messages.....              | 73        |
| Verifying card status .....                              | 74        |
| Verifying Base Station status .....                      | 74        |
| Programming telephony data.....                          | 75        |
| Delay to Dial .....                                      | 75        |
| B03 gain value modification.....                         | 76        |
| Portable telephone side tone .....                       | 77        |
| CMCC slot .....                                          | 78        |
| Programming mobility data .....                          | 79        |
| Setting the antenna type for a radio.....                | 79        |
| Setting the System Access Logical Identifier.....        | 80        |
| Programming the system time and date .....               | 82        |
| Programming the system time .....                        | 82        |
| Programming the system date .....                        | 83        |
| Changing passwords .....                                 | 84        |
| Changing the Installer password .....                    | 84        |
| Changing the Administration password .....               | 85        |
| Changing the Registration password .....                 | 86        |
| <b>Activating wireless communications .....</b>          | <b>89</b> |
| Codes and credits.....                                   | 89        |
| Portable Credit Code .....                               | 89        |
| UTAM Activation Code .....                               | 89        |
| Accessing the Nortel IVR system .....                    | 90        |
| Companion ID.....                                        | 90        |
| System Security Number.....                              | 90        |
| Activating a new system .....                            | 92        |
| <b>Verifying a Meridian Companion installation .....</b> | <b>95</b> |
| Viewing radio and cell assignments.....                  | 97        |
| Identifying a radio's cell assignment .....              | 98        |

|                                                                           |            |
|---------------------------------------------------------------------------|------------|
| <b>Configuring the Meridian 1 for the Meridian Companion system .....</b> | <b>99</b>  |
| X11 release 15 or greater without package 240.....                        | 100        |
| X11 release 20B or greater with package 240 .....                         | 101        |
| Wireless telephone privacy .....                                          | 103        |
| Programming options .....                                                 | 103        |
| <b>Programming user options .....</b>                                     | <b>107</b> |
| Programming Call Transfer on Radio Loss .....                             | 107        |
| Programming a system default for radio loss handling.....                 | 108        |
| Programming individual Transfer on Radio Loss .....                       | 108        |
| <b>Registering and verifying portable telephones .....</b>                | <b>111</b> |
| Enabling and disabling registration.....                                  | 112        |
| Registering portable telephones .....                                     | 112        |
| Verifying a portable telephone's operation .....                          | 113        |
| Verifying Portable Credits .....                                          | 114        |
| Deregistering the WTN .....                                               | 114        |
| <b>Maintenance.....</b>                                                   | <b>115</b> |
| Using maintenance commands .....                                          | 115        |
| Meridian 1 card maintenance .....                                         | 116        |
| Administration Terminal maintenance commands .....                        | 117        |
| Maintenance features .....                                                | 117        |
| System status.....                                                        | 118        |
| Card status .....                                                         | 120        |
| Wireless Terminal Number (WTN) status .....                               | 122        |
| TCM status .....                                                          | 124        |
| Event/Alarm log .....                                                     | 126        |
| Entering the Event/Alarm log.....                                         | 127        |

---

|                                                             |     |
|-------------------------------------------------------------|-----|
| Checking the most recent alarm .....                        | 127 |
| Checking when an alarm or event occurred .....              | 127 |
| Checking consecutive repetitions of an alarm or event ..... | 128 |
| Erasing the log .....                                       | 128 |
| Administration log .....                                    | 129 |
| Entering the Administration log .....                       | 129 |
| Checking when an event occurred.....                        | 130 |
| Checking the most recent alarm.....                         | 130 |
| Checking consecutive repetitions of an event or alarm ..... | 130 |
| Erasing the Administration log .....                        | 131 |
| Responding to event and alarm messages .....                | 131 |
| Responding to an alarm code.....                            | 131 |
| System Reevaluation .....                                   | 132 |
| Scheduling System Reevaluation .....                        | 136 |
| Modifying your system .....                                 | 138 |
| Adding Portable Credits .....                               | 138 |
| Adding Radio Credits .....                                  | 139 |
| Activating a disabled system.....                           | 140 |
| Replacing equipment .....                                   | 141 |
| Adding or moving Base Stations.....                         | 141 |
| Replacing a defective Base Station .....                    | 143 |
| Adding expansion cards .....                                | 144 |
| Relocating the system .....                                 | 145 |
| Replacing a defective expansion card .....                  | 148 |
| Replacing a defective ROM card .....                        | 149 |
| Replacing a defective CMCC.....                             | 152 |
| Replacing a defective remote power interconnect unit .....  | 152 |
| Replacing a defective Remote Access Device .....            | 154 |
| Replacing a defective Administration Terminal .....         | 154 |
| Portable .....                                              | 154 |
| Entering codes for system replacement and recovery.....     | 154 |
| Handling Meridian Companion exceptions .....                | 156 |
| Config warning: Recoverable inconsistency .....             | 156 |
| Config failure: Nonrecoverable inconsistency .....          | 157 |

|                                                       |            |
|-------------------------------------------------------|------------|
| <b>Troubleshooting .....</b>                          | <b>159</b> |
| General troubleshooting procedures .....              | 159        |
| Troubleshooting power problems.....                   | 161        |
| Troubleshooting cards .....                           | 161        |
| Normal card LED behavior .....                        | 162        |
| Troubleshooting the Administration Terminal .....     | 164        |
| Troubleshooting a Base Station.....                   | 165        |
| Troubleshooting a remote power interconnect unit..... | 166        |
| Troubleshooting portable telephone problems .....     | 168        |
| Verifying Radio Credits .....                         | 170        |
| Troubleshooting a RAD .....                           | 170        |
| Troubleshooting an alarm .....                        | 171        |
| Understanding event messages .....                    | 177        |
| <b>Appendix A: Programming overview.....</b>          | <b>181</b> |
| <b>Appendix B: Regulatory information.....</b>        | <b>183</b> |
| Federal Communications Commission (FCC) .....         | 183        |
| Activation .....                                      | 183        |
| Registration .....                                    | 183        |
| Safety .....                                          | 184        |
| Equipment attachment limitations .....                | 185        |
| Telecom compliance .....                              | 186        |
| Telephone company notification .....                  | 186        |
| Rights of the telephone company .....                 | 187        |
| Radio Frequency Interference .....                    | 187        |

|                                  |            |
|----------------------------------|------------|
| Ringer Equivalence Number .....  | 188        |
| Repair facility .....            | 188        |
| Note for hearing aid users ..... | 188        |
| <b>List of terms.....</b>        | <b>189</b> |
| <b>Index.....</b>                | <b>197</b> |